



Numbers at the top and left of page are consistent and can be used as a shortcut to particular sub-menu choices.

**For example:** Sub-menu 2.3 can be located by placing your finger at Box 2 on the left side of the page, and other finger at Number 3 at the top of the page. Simply follow them across the page perpendicular to each other. Where they meet is sub-menu 2.3

